Squid PCI Express Gen3 Carrier Board™ for 2 M.2 SSD modules

Hardware Manual

October 14, 2016 Revision 1.0

Contents

1	About this Document			
	1.1	Purpose	1	
	1.2	Feedback	1	
	1.3	Revision History	1	
2	Gener	al Description	2	
	2.1	Introduction	2	
	2.2	Package Contents	2	
3	Featur	Features		
	3.1	Features	6	
	3.2	PCI Express Carrier board for 2 M.2 SSD modules interfaces connection	7	
4	Installa	ation	8	
	4.1	Carrier board installation	8	
5	Hardware Description			
	5.1	Board Layout	9	
	5.2	LEDs	10	
	5.3	Connectors	10	
6	Appen	dix A:	11	
7	Appen	dix B: Limited warranty	12	
Fig	ures			
Figure Figure Figure	e 2: PC e 3: PC e 4: Ca	I Express Gen 3 Carrier Board for 2 M.2 SSD modules I Express Gen 3 Carrier Board for 2 M.2 SSD modules (top) I Express Gen 3 Carrier Board for 2 M.2 SSD modules (bottom) rrier board PCI Express connection I Express Carrier Board for M.2 modules layout	4 5 7	

Tables

Table 1: PCI Express Carrier Board for M.2 modules LEDs	. 10
Table 2: PCI Express Carrier Board for M.2 modules connectors	. 10

1 About this Document

1.1 Purpose

This document describes hardware installation, features, specification and operation of the *Squid* PCI Express Gen 3 Carrier BoardTM for 2 M.2 SSD modules from AMFELTEC Corporation.

1.2 Feedback

AMFELTEC Corp. makes every effort to ensure that the information contained in this document is accurate and complete at time of release. Please contact AMFELTEC Corp. if you find any errors, inconsistence or have trouble understanding any part of this document.

To provide your feedback, please send an email to support@amfeltec.com

Your comments or corrections are greatly valued in our effort for excellence and continued improvement.

1.3 Revision History

Rev. No.	Description	Rev. Date
1.0	Initial Release.	October 14, 2016

2 General Description

2.1 Introduction

Squid PCI Express family is a series of PCI Express Carrier Boards designed for expansion of any desktop computer or embedded appliance. Squid family expands a motherboard's PCI Express or USB slot with multiple full/half size MiniPCI Express or M.2 modules.

PCI Express Carrier Board for M.2 SSD modules occupies the space equal to standard one-slot wide PCI Express board defined by PCI Express Specification. Carrier board is half height/half length PCI Express board. It is located in the middle of the PCI Express slot and connects to the motherboard PCI Express connector via exchangeable x4 or x8 PCI Express adapters. This unique PCI Express structure (patent pending) allows allocating multiple M.2 modules on the top and bottom sides of the carrier board, and not violating PCI Express Specification.

M.2 (M key) circuits located on the Carrier board support any M.2 PCI Express M key modules with any standard length (2230/2242/2260/2280 and 22110).

2.2 Package Contents

PCI Express Gen 3 Carrier Board for 2 M.2 SSD modules package (depending on the SKU part number) includes the following parts:

- 1. PCI Express Gen 3 Carrier Board for 2 M.2 modules (Figure 1,2,3)
- 2. x4 or x8 PCI Express Adapters
- 3. Full or half size PCI Express bracket



Figure 1: PCI Express Gen 3 Carrier Board for 2 M.2 SSD modules




Figure 2: PCI Express Gen 3 Carrier Board for 2 M.2 SSD modules (top).



Figure 3: PCI Express Gen 3 Carrier Board for 2 M.2 SSD modules (bottom).

3 Features

3.1 Features

- Easy 'Plug and Play" installation
- Supports up to 2 M.2 PCI Express add-in modules (M key)
- x4 PCI Express (Gen 3) connection to each M.2 circuit
- One slot wide, Half-length / half-height PCI Express board; x4 or x8 upstream PCI Express (Gen 3) interface
- Supports PCI Express Gen 3 (8.0 Gbps) operation
- Easy removable Cooling Fan
- Meets PCI Express 2.1 and M.2 1.0 Specifications
- Dimension 178 mm. x 65 mm.
- RoHS compliant

3.2 PCI Express Carrier board for 2 M.2 SSD modules interfaces connection.




Figure 4: Carrier board PCI Express connection.

4 Installation

4.1 Carrier board installation

Following steps provide the exact sequence that needs to be followed in order to properly install the Amfeltec PCI Express Expansion Carrier Board:

- Turn OFF computer before installation
- Remove the chassis cover from the computer
- Locate an unused PCI express slot and remove the corresponding slot cover from computer chassis
- Plug-in Carrier Board to PCI express slot and attach its bracket to the computer chassis with a screw
- Put the chassis cover back on the computer
- Turn ON computer

5 Hardware Description

5.1 Board Layout




Figure 5: PCI Express Carrier Board for M.2 modules layout

5.2 LEDs

Name	Ref. Des	Color	Usage
RESET	D39	RED	Global PCI Express RESET signal from
UPSTREAM	D40	GREEN	Upstream PCI Express Link status.
STATUS	D46	YELLOW	PCIe Switch status.
LINK1	D41	GREEN	Status of the downstream x4 PCIe Link to U26
LINK2	D42	GREEN	Status of the downstream x4 PCIe Link to U28

Table 1: PCI Express Carrier Board for M.2 modules LEDs

5.3 Connectors

Ref. Des.	Type	Usage
J36, J37	Connectors	Connection to the x4 or x8 PCI Express Adapter
J50	Connector	Removable Cooling Fan Connection
U26	M.2 connectors (M key)	M.2 add-in modules connection (top side)
U28	M.2 connectors (M key)	M.2 add-in modules connection (bottom side)

Table 2: PCI Express Carrier Board for M.2 modules connectors

6 Appendix A:

7 Appendix B: Limited warranty

AMFELTEC Corporation does not warrant that the operation of the hardware, software or firmware products will be uninterrupted or error free. AMFELTEC products are not intended to be used as critical components in life support systems, aircraft, military systems or other systems whose failure to perform can reasonably be expected to cause significant injury to humans. AMFELTEC expressly disclaims liability for loss of profits and other consequential damages caused by the failure of any product which would cause interruption of work or loss of profits, such as shipboard or military attachment.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED. THE WARRANTIES PROVIDED HEREIN ARE BUYER'S SOLE REMEDIES. IN NO EVENT SHALL AMFELTEC CORPORATION BE LIABLE FOR DIRECT, SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES SUFFERED OR INCURRED AS A RESULT OF THE USE OF, OR INABILITY TO USE THESE PRODUCTS. THIS LIMITATION OF LIABILITY REMAINS IN FORCE EVEN IF AMFELTEC CORPORATION IS INFORMED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the exclusion or limitation on incidental or consequential damages, so the above limitation and exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.